

Air differential pressure sensor dual

Differential pressure transmitter with two independent measuring systems. With each 8 selectable ranges and one output 0...5 V/10 V. For monitoring the differential pressure of air and other non-flammable and non-aggressive gases. Typical application in HVAC systems for monitoring air filters, fans V-belts or fire and smoke control dampers. Options available with LCD display. IP65 / NEMA 4X rated housing.



Picture may differ from product

Type Overview

Type	Measuring range [Pa]	Output signal active pressure	Burst pressure	Display type
22ADP-124D	-100...2500	0...5 V, 0...10 V	40 kPa	-
22ADP-124F	-100...2500	0...5 V, 0...10 V	40 kPa	LCD

Technical data

Electrical data	Nominal voltage	AC/DC 24 V		
	Nominal voltage range	AC 19...29 V / DC 15...35 V		
	Power consumption AC	4.3 VA		
	Power consumption DC	2.3 W		
	Electrical connection	Pluggable spring loaded terminal block max. 2.5 mm ²		
	Cable entry	Cable gland with strain relief ø6...8 mm		
Functional data	Medium	Air		
	Multirange	8 measuring ranges selectable		
	Voltage output	2 x 0...5 V, 0...10 V, min. resistance 10 kΩ		
	Analogue output	Output 0...5/10 V selectable with switch		
	Display	LCD, 29x35 mm with backlight Measured values: Pa, inch WC (configurable)		
	Typical response time	Adjustable 0.8 s or 4.0 s		
Measuring data	Measured values	Differential pressure Volumetric flow (with A-22G-A05)		
	Measuring fluid	Air and non-aggressive gases		
Specification Pressure	Sensing element technology	Piezo measuring element		
	Measuring range	-100...2500 Pa		
	Measuring range pressure settings	*del*Setting	Range [Pa]	Range [inch WC] FactorySynonyms setting
		S0	0...2500	0...10 ✓
		S1	0...2000	0...8
		S2	0...1500	0...6
		S3	0...1000	0...4
		S4	0...500	0...2
		S5	0...250	0...1
		S6	0...100	0...0.4
		S7	-100...100-0.4...0.4	

Technical data

Specification Pressure	Accuracy	Deviation compared to the reference device measuring range ≤ 500 Pa: ± 5 Pa measuring range > 500 Pa: ± 10 Pa
	Long term stability	$\pm 2.5\%$ FSO (Full Scale Output) / 4 yr.
Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)
	Power source UL	Class 2 Supply
	Degree of protection IEC/EN	IP65
	Degree of protection NEMA/UL	NEMA 4X
	Housing	UL Enclosure Type 4X
	EU Conformity	CE Marking
	Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-6
	Quality Standard	ISO 9001
	UL Approval	cULus acc. to UL60730-1A/-2-6, CAN/CSA E60730-1
	Type of action	Type 1
	Rated impulse voltage supply	0.8 kV
	Pollution degree	3
	Ambient humidity	Max. 95% RH, non-condensing
	Ambient temperature	$-10 \dots 50^{\circ}\text{C}$ [$14 \dots 122^{\circ}\text{F}$]
	Fluid temperature	$-10 \dots 50^{\circ}\text{C}$ [$15 \dots 120^{\circ}\text{F}$]
Materials	Housing	Cover: PC, orange Bottom: PC, orange Seal: NBR70, black UV resistant
	Cable gland	PA6, black

Safety notes



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorised modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.


The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

Remarks

Manual zero-point calibration	After initial commissioning
	To carry out the zero-point calibration, the device must be connected to the power supply at least 15 minutes beforehand.
	Calibration interval
	≤ 250 Pa 3 months
	≤ 500 Pa 6 months
	> 500 Pa 12 months
	Procedure
	• Release both tube connectors from the pressure ports + and - (Carry out the manual zero-point calibration even if the display shows 0.)
	• Press the button "Manual zero-point calibration" until the LED lights permanently
	• Wait until the LED flashes again and reinstall the tube connectors to the pressure ports (pay attention to + and -)

Indicators

Indicators Depending on the device and the number of measured values, the display automatically scales. Parameters, such as the fading in/out of measured values, brightness and traffic light function, are changed via the app or bus system. During the boot process, the software and hardware versions are displayed.



- 1 Fault / sensor failure
- 2 Service / visual inspection due
- 3 TLF (traffic light function) active (thresholds for display colour changes)
- 4 Radio active (not available)
- 5 Status bar
- 6 Measured value (* appears when TLF function is activated for this value)
- 7 Unit of measure
- 8 Measured value

Parts included

Description	Type
Mounting plate L housing	A-22D-A10
Duct connector kit, PVC tube 2 m, 2x duct connector (plastic) for 22ADP-..	A-22AP-A08
Dowels	
Screws	

Accessories

Optional accessories	Description	Type
	Duct connector, L 40 mm, metal, Tube connection 5 mm	A-22AP-A02
	Duct connector, L 100 mm, metal, Tube connection 5 mm	A-22AP-A04
	Connection adapter flex conduit, M20x1.5, for cable gland 1x 6 mm, Multipack 10 pcs.	A-22G-A01.1
Tools	Description	Type
	Belimo Duct Sensor Assistant App	Belimo Duct Sensor Assistant App
	Bluetooth dongle for Belimo Duct Sensor Assistant App	A-22G-A05
Mechanical accessories	Description	Type
	Duct connector kit, PVC tube 2 m, 2x duct connector (plastic) for 22ADP-..	A-22AP-A08
	* Bluetooth dongle A-22G-A05	
	Certified and available in North America, European Union, EFTA States and UK.	

Wired connection This sensor can be operated and configured using the Belimo Duct Sensor Assistant App. When using the Belimo Duct Sensor Assistant App, the bluetooth dongle is required to enable communication between the app and the Belimo sensor.


For standard operation and configuration of the sensor, the bluetooth dongle and the Belimo Duct Sensor Assistant App are not needed. The sensor will arrive pre-configured with the factory default settings shown above.

Requirement:


- Bluetooth dongle (Belimo Part No: A-22G-A05)
- Bluetooth-capable smartphone
- Belimo Duct Sensor Assistant App (Google Play & Apple App Store)

Procedure:


- Plug the Bluetooth dongle into the sensor via the Micro-USB connector or by means of the interface PCB
- Connect Bluetooth-capable smartphone with Bluetooth dongle
- Select configuration in the Belimo Duct Sensor Assistant App



Wiring diagram



Dimensions



Type

22ADP-124D

22ADP-124F

Weight

0.44 kg

0.48 kg

Further documentation

- Installation instructions